

## Pecan Pralines

1 1/4 cups of sugar  
3/4 cups of packed brown sugar  
1 small can of evaporated milk  
4 tablespoons frozen butter  
1 tablespoon vanilla  
1 1/2 cups pecan pieces

Put sugars & milk in heavy bottom pan & cook to soft ball stage. Take off fire & add frozen butter, vanilla & pecans. Stir until some of the shine leaves mixture & then spoon on to waxed paper. (Be careful and don't overcook).

Contributed by: Barbara Lawrence